

TANDEM•1

PENETRATING STAIN

(Interior Wood Surfaces
Furniture • Walls • Woodwork)



Easy to apply

Creates no surface film

Easy to maintain

Repairable

Enhances the wood character

1 Sand
100 - 120

Sand with a 100 to 120 grit sandpaper.
Dust off with a dry cloth.
(No damp cloth)

2 Tools

Apply with a cotton cloth, an applicator pad, a brush or a sheepskin.

3 Wipe
After 15 min

Wipe in the direction of the wood grain to eliminate any excess.



4 Drying
24 h

2 to 3 coats
+ 24 hours: Apply the 2nd or 3rd coat.
+ 24 hours: Apply finition.
* Finish: Tandem-2 oil, varnish or wax water based.

5 Colouring

Add natural stain to lighten.
Apply a second coloured coat to darken the colour.

Coverage
150 - 300
sq. ft./L

Refer to the chart of covering powers in your Merchant Guide.

* For maple or dense wood: Wet with a mop or a damp cloth. Allow to dry for about 2 hours, sand lightly with a 220 grit sandpaper to break the wood grain and dust thoroughly with a dry cloth.

Add a second coat to increase gloss, colour intensity and water resistance.

COMBUSTION DANGER Keep out of the reach of children. Materials used with this product, such as rags, may ignite spontaneously. After use, soak the rags in water or dry them flat, then discard.

FINISHING OIL

(For Solidified Interior Wood Surfaces
Furniture • Walls • Woodwork)

TANDEM•2

VOC



1 Sand
100 - 120

Sand with a 100 to 120 grit sandpaper.
Dust off with a dry cloth.
(No damp cloth)

2 Tools

Apply with a cotton cloth, an applicator pad, a brush or a sheepskin.

3 Wipe
After 15 min

Wipe in the direction of the wood grain to eliminate any excess.

4 Drying
24 h

+ 24 hours: Apply the 2nd or 3rd coat.

5 Coats
1-2 or 2-3

Number of coats:
Used alone: 2 to 3 coats
Applied on TANDEM 1: 1 to 2 coats

Coverage
150 - 360
sq. ft./L

Refer to the chart of covering powers in your Merchant Guide.

Protects against moisture

Can be used alone or with a stain

Easy to apply

Creates no surface film

Easy to maintain

Repairable

* For maple or dense wood: Wet with a mop or a damp cloth. Allow to dry for about 2 hours, sand lightly with a 220 grit sandpaper to break the wood grain and dust thoroughly with a dry cloth.

Add a second coat to increase gloss and water resistance.

Gloss : Matt satin